



RESOURCE LIBRARY - STEWARDING
Operation of Vacuum Machine操作吸水器

CODE: 03.16.067

EDITI
ON: 1

PAGE 1 OF 1

Standard:

The Vacuum machine must be maintained and must be operated as per instructions to prevent accident and damage.

标准:

要正确操作和保养高压水枪避免事故和损坏的发生。

Procedures:

Ensure that power not lowering.

1. Check that all parts of machine are complete.
2. Connect all part of machine in proper order.
3. Connect electric power and switch on.
4. Switch off immediately when container was full.
5. Pour off water into drain and reset.
6. Switches off first when complete your work.
7. Disconnect all part of machine and clean them.
8. Clean container.
9. Clean exterior of machine and sent it backs to store.

NB: Never moves machine by dragging.

Do not bump, it's very important for vacuum machine.

Never use machine continuously when container is already full.

-End-

程序:

确保电压良好。

1. 检查机器部件是否齐备。
2. 按顺序连接好各部件。
3. 连接电源并打开。
4. 当储水筒满时要立即关闭电源。
5. 将水倒入排水沟后重新启动机器。
6. 当工作结束时首先关掉机器。
7. 拆开各部件并清洁。
8. 清洁储水筒。
9. 清洁机器外表后将机器送回库房。

注意: 移动机器时不要拖拉。

不要碰撞吸水器, 这一点对吸水器来讲是非常重要的。
当储水筒已满是不要继续使用吸水器。

-完-